

HOSELINK®


Single Outlet Bluetooth Tap Timer



SKU - 5838

USER MANUAL

Meet the Tap Timer



Bluetooth Range: 5m without interference
 Pressure operating range: 2.9-116 psi
 Temperature operating range: 4.5°C-45 °C
 For outdoor use with cold water only
 Not for use with appliances

1

Initial App Setup

1) Download the 'Smart Life' or 'Tuya Smart' App
 If you don't already have the 'Smart Life' or 'Tuya Smart' apps on your device, search "Smart Life" or "Tuya Smart" and download the free Android or IOS app.

2) Open the App
 Create an account or login with an existing account to begin timer setup.

3) Enter Configuration Mode on Timer
 Press and hold the On/Off button for 6s until the green light flashes quickly, the Timer has now entered pairing mode.

4) Add a Device
 Tap "Add device" or "+" to add the smart device in app. Wait for Timer to connect. Once connected, you can edit the name of your timer.

2


Meet the App Home Screen



3


Press the "Timing" button and then the "+", you can set "Normal Schedule" or "Cycle/Soak" watering program.
Normal Setting:
 Use to set watering to come on at a set time on a set day of the week.
Cycle/soak:
 Use to set watering to come on at a set time and then again in set time periods thereafter. You can set up 10 programs between Normal & Cycle/soak settings.

Normal Schedule



4

Cycle/Soak



Whole Schedule: During 10:00AM to 10:00PM, the timer will cycle watering program for 5 mins and stop for 6hrs. The timer will watering at 10:00-10:05AM and 4:05-4:10PM.

5

Initial Water Timer Setup

1) Insert Two AA Batteries
 Batteries are not included and you will need two alkaline AA batteries to power your timer. Remove the battery tray and install the batteries according to the drawings located in the tray. Firmly reinstall the battery tray back into the timer.

2) Install the Timer
 Connect the timer to an outdoor tap. Your timer is now ready to be used with any product that can be attached to a standard tap.

⚠ Do not place the timer in an underground valve box or anywhere your Bluetooth signal will be obstructed.

3) Turn on Your Water
 The water must remain on for the timer to work properly.

6

Additional Functions for Water Timer

Manual Watering
 Your timer has the ability to allow you to manually water without disturbing the programmed schedule. Manual is used to test equipment, run an extra watering cycle in an area, or to use the tap without removing the timer. Press the ON/OFF button to activate manual watering. Using the app you can set how long you want the preset manual cycle to run for.

Stop Watering
 You can stop the flow of water at any time whether it is during manual watering, or during a programmed time. Press the ON/OFF button once to stop watering.

7

Maintenance Tips

When expecting freezing temperatures, timer should be removed from the tap and stored indoors to avoid potential freeze damage. Please remember to clean the filter regularly and replace it if worn.

Troubleshooting

- Q: Why the water timer didn't turn on/off at preset time?
 A:
1. Programming is incorrect
 2. Water pressure is too low
 3. Particles of dirt or debris stuck in valve
 4. More than one start time is programmed with overlapping schedules
 5. Manual watering is on
 6. Faulty valve
 7. The tap is off

Support

If you have any questions about our product, please feel free to contact us on 1300 900 617 or email hello@hoselink.com.au.

8