



Wi-Fi Gateway for Single & Double Outlet Bluetooth Tap Timers



USER MANUAL



Use this Wi-Fi Gateway with Hoselink Bluetooth Tap Timers to enable internet connection so they can be controlled from anywhere. If you have purchased a Bluetooth Tap Timer and Wi-Fi Gateway at the same time, we suggest connecting the gateway first, then the timer.

Download the app

If you don't already have the 'Smart Life' or 'Tuya Smart' apps on your phone, search "Smart Life" or "Tuya Smart" and download the free Android or IOS app.

Set up the Wi-Fi Gateway

1. The Wi-Fi Gateway should be used indoors, located within range of both your home Wi-Fi modem and the outdoor timer (check the timer manual for Bluetooth range).
2. Plug the Wi-Fi Gateway into a power socket and turn on the power.

Pair the Wi-Fi Gateway

1. Press and hold the Wi-Fi Gateway control button for 5s until the green light flashes quickly. It is now in gateway pairing mode.
2. In the app, tap “add device” or “+” to add the Wi-Fi Gateway.
3. Enter Wi-Fi information including your home Wi-Fi network and password (this may autofill if your phone is already connected to this network).
4. Wait for it to connect to the app and once connected, you can edit the name of the gateway.

Connect the Wi-Fi Gateway to the

1. In the app, open the “Wi-Fi Hub”.
2. Press and hold the button on the timer for 5s until the LED light rapidly flashes.
3. In the app tap “add device” to add the timer in the gateway then select “add new device”.
4. Wait for the timer to connect. Once connected, you can edit the name of your timer.
5. We recommend modifying timer settings through the

NB. The Wi-Fi Gateway can connect to multiple tap timers and devices, including other smart devices that work with either the Smart Life or Tuya apps.



MADE IN CHINA