


# HOSELINK<sup>®</sup>


## Dual Outlet Bluetooth Tap Timer

SKU - 5839



### USER MANUAL

## 1. Meet the Dual Hose Tap Timer



### Specification:

|                        |                          |
|------------------------|--------------------------|
| Bluetooth Range        | 15m without interference |
| Working Water Pressure | 7.25-116 psi             |
| Working Temperature    | 4.5°C-45°C               |
| Rain Delay Time        | 1 day and up to 7 days   |
| Waterproof             | IPX5                     |
| Battery                | 4x AA alkaline batteries |

## 2. Initial Water Timer Setup

### 1 Insert 4x AA Batteries

1. Remove the tray on the back of the timer by sliding or pulling it out.
2. Insert four AA (1.5V) alkaline batteries and replace the tray.

#### **! Note:**

Please do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

### 2 Install the Timer

Connect the timer to an outdoor tap Your timer is now ready to be used with any product that can be attached to a standard tap .

#### **! Note:**

Do not place the timer in an underground valve box or anywhere your Bluetooth signal will be obstructed.

### 3 Turn on Your Water

The water must remain on for the timer to work properly.

## 3. Initial App Setup

### 1 Download the 'Smart Life' or 'Tuya Smart' App

If you don't already have the 'Smart Life' or 'Tuya Smart' apps on your device, search "Smart Life" or "Tuya Smart" and download the free Android or IOS app.



### 2 Enter configuration Mode

Press and hold either of the On/Off buttons for 6s until the two green lights flash quickly at the same time to place the water timer in pairing mode.

**3**

### Open the App


Create an account or login with an existing account to begin timer setup.

**4**

### Add a Device

Tap "Add device" or "+" to add the smart device in app. Wait for timer to connect. Once connected, you can edit the name of your timer.




## 4. Meet the App Home Screen





## 5. Additional Water Timer Features

### 1 Manual Watering

Your timer has the ability to allow you to manually water without disturbing the programmed schedule. Manual is used to test equipment, run an extra watering cycle in an area, or to use the hose tap without removing the timer.

Click the   button to activate manual watering. Using the app you can click  to set how long you want manual watering time to run for. The "work time" will also display the remaining watering time.

### 2 Stop Watering

You can stop the flow of water at any time whether it is during manual watering, or during a programmed time. Click the   button once again to stop watering. (NOTE: icon without water droplets)

The rain delay function allows you to postpone watering for 1 day and up to 7 days due to rain or when the ground is already wet. Using the app, you can set how long the rain delay will last.

## 6. Troubleshooting

Q1: Why didn't the Bluetooth timer turn on/off at the preset time?

### A1:

- Programming is incorrect
- Water pressure is too low
- Particles of dirt or debris stuck in valve
- More than one start time is programmed with overlapping schedules
- Manual watering is on
- Faulty valve
- The batteries were low
- The tap is off.



Q2: Why does Bluetooth connection keep dropping?

A2:

- The timer is currently in sleep mode, please wait 5-10 seconds and the timer will automatically reconnect. If not, scroll down on the app home page to refresh. Or, disconnect and then reconnect your phone Bluetooth.
- If the device has been connected by other mobile phones, please disconnect first.
- Make sure the device battery is charged and place the phone as close to the device as possible.
- Please note that you don't need to stay connected once you setup your schedule. The device will always keep your watering settings and work automatically according to the schedule.

Q3: Why isn't the valve letting much water through?

A3:

If you are using a gravity fed system such as rain water tanks, then the timer may produce very little water pressure. Gravity fed tanks have low pressure and this can affect how the timer operates.

## 7. Maintenance Tips :

- The best range for connection and control is within 15m in an open area.
- The bluetooth water timer does not support Alexa & Google voice or remote control.
- Do not use your timer when the air temperature is below 4.5°C , the timers should be removed from the tap and stored indoors to avoid potential frost damage.
- Filter can trap dirt particles, please clean filter regularly and replace if worn.
- Please replace batteries when the low battery indicator appears in the display. When replacing the power unit, please make sure that the water timer is dry.
- To prevent leakage, make sure that the water timer is tightly attached to the tap and hose, add rubber washer and thread seal tape if necessary.

### **! Note:**

- (1) The water flow is reduced by half when the two zones are turned on at the same time.
- (2) The water flow in two zones may be different if you turn on one zone first and then turn on the other zone.