

Storing the Lights

Manually switch the power to 'OFF'. This will preserve the battery and prevent it from fully discharging during extended storage.

Specifications

Solar Panel	Polycrystalline
Lithium Battery	4.4V / 2000mAh
Operating Time	20-40 hours
Charge Time	5.5 hours
Battery Replaceable	Yes
Light Temperature (Kelvins)	4000 K
LED Lumens	700 Lumens
Number of LEDs	Top light: 6 Bottom light: 15
Waterproof Rating	IP65
Recommended Mounting Height	2.5m
Effective Range	7.8m ²
Colour	White

WARNING: DO NOT USE THIS LIGHT UNDERWATER OR IN LOW-LYING PUDDLES.

MODEL: L111

Solar Up & Down White Wall Lamp
10 LED | DOME

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink

User Manual

MODEL: L111

Solar Up & Down White Wall Lamp
10 LED | DOME



HOSELINK[®]

Kit Contents

- 1 x Solar White Up & Down Wall Light**
- 1 x Hardware Kit (2 x screws, 2 x masonry plugs)**
- 1 x Post Accessories (2 x nylon cable ties)**

The Solar Dome Up and Down Light features a distinctive curvy design that sets it apart from traditional outdoor lighting. Its smooth, rounded edges create a modern and sleek profile, blending seamlessly with both contemporary and classic architectural styles.

Lighting Modes

Solar White Up & Down Wall Light has 4 lighting modes:

- 1 25%
- 2 50%
- 3 75%
- 4 100%

Activate the Light

To turn on the solar light, press the 'Power' button located on the front top for 2 seconds. To test the light, cover the solar panel with your hand and check if the light comes on.

After activating the light, use the 'Power' button to select your preferred lighting mode. The solar panel features a built-in intelligent light sensor that automatically detects darkness, turning the light on at dusk and off at dawn.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum results; preferably 6-8 hours per day.

STEP 2 Install the Light

Product Installation - Option A

Using adhesive outdoor tape

- A.1** Adhere using Hoselink Outdoor Acrylic Double-Sided tape (SKU L100), sold separately. Be sure to stick the tape onto the mounting plate on the back of the light.

Product Installation - Option B

Using supplied hardware

- B.1** Slide mounting plate off the light and use as a template.

- B.2** Mark out 2 holes with a marker pen.

- B.3** Drill the holes using a 6mm drill piece for masonry installation. Gently hammer the plugs into place and then secure the screws tightly.

- B.4** For timber, drill 3mm pilot holes to guide the screws into place (plastic plugs are not required).

- B.5** Slot the Solar White up & Down Wall Light over the mounting plate and slot into place (plastic plugs are not required).

Clean the solar panel periodically to maintain optimal performance.

Product Installation - Option C

Horizontal installation

- C.1** Use cable ties to cross through the holes in the mounting plate and around a vertical post.

Vertical installation

- C.2** Use cable ties to cross through the holes in the mounting plate and around a horizontal post.